

Dust Test Equipment

Description:

The dust chamber, as specified in the standard, incorporating blower, circulating ducting and agitation. A standard headform and suitable reflectometer head and digital display of reflectance are included, together with an adequate supply of the required dust.

Services required:

Floor mounted. 230vac, 50Hz mains electricity.

Approximate packed size & weight:

200 x 60 x 80 cm : 100 kg

Relevant standard:

BS EN 168 : 2001, para 13

Delivery: 16 weeks from receipt of order and deposit.

Effective: May 2008

