

## **Calibration lenses for telescope & target test equipment**

### ***Description:***

The telescope and target equipment, as supplied by INSPEC, is calibrated before shipping. However, in order to re-calibrate the focussing of the telescope subsequently, lenses of known power may be used, as described in EN 167.

The set of lenses comprise one lens each, of the following nominal powers:

+0.06, +0.12, +0.25, -0.06, -0.12, -0.25 D.

Independent, traceable calibration of the actual powers of the lenses can also be provided, including a UKAS calibration certificate.

### ***Services required:***

None.

### ***Approximate packed size & weight:***

20 x 10 x 10cm, 1Kg.

### ***Relevant standard:***

BS EN 167 : 2002, para 3.1.1.4

### ***Delivery:***

Lenses only - approximately 6 weeks from receipt of order and deposit.  
For UKAS calibration, add a further 6 weeks approximately.

Effective: May 2008

